

The headset is equipped with a stereo / monaural switch on the non-mic side ear cup. For monaural sound or aircraft with only monaural jacks, move the switch to the monaural position. In aircraft equipped for stereo audio, move the switch to the stereo position.

The headset parts may be cleaned with mild soap and water using a soft cloth. Then dry immediately. **Caution: Do Not immerse** any part of the headset in water or any other liquid. Be especially careful not to allow the microphone to become wet! Exposure to moisture may cause internal corrosion and failure and will void your manufacturers warranty.

Cleaning will help the headset maintain its "like new" condition for many years.

WINDSCREEN

The microphone windscreen will reduce annoying wind noise and breath pops picked up by headset microphones. It also protects the microphone element from dirt and moisture. The windscreen should be washed regularly to maintain hygiene and avoid clogging. Wash in warm water and mild soap. Rinse thoroughly and make sure it is completely dry before putting it back on.

To remove the windscreen, take out the screw that holds the microphone on the boom and grasp the windscreen lightly along its entire length and slip it off.

Put the windscreen on the microphone by gently pulling from the open end. Do not pull it so tightly that it stretches against the end of the microphone.

WARRANTY

Your headset is covered by a limited five-year parts and labor warranty. Please see the enclosed warranty card for details.

You may refer to the parts list on the reverse side, if you choose to replace parts yourself. The parts list describes parts for this particular headset only. Parts lists for other models are available on our Web Site or can be obtained by contacting Sigtronics Corporation.



Sigtronics Corporation
178 East Arrow Highway
San Dimas, CA 91773
Phone: 909 305-9399
E-mail: info@sigtronics.com
Web Site: www.sigtronics.com

Model S-65S Headset Instructions

The S-65S series headsets are adjusted at the factory for immediate use with all current standard radio systems in general aviation aircraft. Headsets equipped with two plugs are the standard configuration. The headphone plug is the larger diameter plug and should be inserted into the headphone jack (.250" standard monaural jack). The mic plug is the smaller diameter plug and should be inserted into the microphone jack (.206" standard microphone jack).

The headband is adjustable through a full range of motion, or the locking nuts may be tightened to allow you to custom fit the headset. Place the headset over your head, adjust the slides up until minimum pressure is felt on the top of your head. The headset is now properly adjusted. For maximum noise attenuation, the clamping pressure has been set at the factory. Releasing the clamping pressure by bending the headband is not advised, because loss of attenuation will result. **Note:** If especially small (children) or large headbands are needed, they may be ordered from Sigtronics.


The microphone boom is fully adjustable and will rotate 360 degrees for use on the left or right side of the head. The locking screw that secures the boom to the ear cup is factory set to insure the correct tension. Turning it will not change the tension, because the nut on the inside of the cup will turn as well. **Microphone placement should be at the corner of the mouth, approximately 1/4" from the lips.** The exclusive thumbscrew on the mic boom may be used to assure proper adjustment.

When you first connect the headset, turn the volume controls on the headset to maximum (full clockwise on mic side, counterclockwise on pot side), then adjust the listening volume with the audio control of either your radio or intercom as appropriate. Passengers should also turn their individual headset volumes up fully. Doing this allows for a full range of adjustment for each passenger, since those with the most acute hearing can turn their headset volume down, if necessary.

continued on back...



...when it counts!



SIGTRONICS S-65S HEADSET PARTS IDENTIFICATION BREAKDOWN

ITEM	P/N	DESCRIPTION	ITEM	P/N	DESCRIPTION	ITEM	P/N	DESCRIPTION
1	100049	GROMMET, 5/16 INCH, RUBBER	17	100610	CUSHION, HEADBAND, FOAM FILLED	33	800082	MICROPHONE, ELECTRET, M-80
2	100360	KNOB, BLACK, VOLUME	18	100423	RECEIVER MOUNT, HEADSET, STEREO	34	100371	MICROPHONE CABLE CLIP
3	100365	POTENTIOMETER, 2K	19	100373	SLIDE, YOKE BRACKET, LONG, NYLON	35	100532	SCREW, THUMB, MICROPHONE BOOM, 2-56 X 1
4	100083	RECEIVER, 300 OHM, STEREO	20	100374	FOAM, SOUND ATTENUATING. NOTCHED, 1/2 INCH	36	100569	STRAIN RELIEF, CABLE
5	100108	SCREW, 4-40 X 1/4, THREAD FORMING	21	100376	FOAM, SOUND ATTENUATING. RECEIVER HOLE, 1/2 INCH	37	900084	WINDSCREEN, MICROPHONE
6	100525	BOOM, ELECTRET MICROPHONE SUPPORT, SWIVEL	22	100379	FOAM, SOUND ATTENUATING, RECEIVER COVER, 1/4 INCH	38	100579	CLIP, CLOTHING, HEADSET CABLE
7	100743	E-RING, EAR CUP TO YOKE RETAINER, BLACK	23	100162	WIRE, 3 CONDUCTOR, #24, BLACK, 28.5 INCHES	39	100530	NUT, STEREO / MONO SWITCH
8	100524	NUT, HEX, 8-32, LOCKING	24	100258	CLIP, HEADBAND GUIDE, PLASTIC	40	100509	SWITCH, STEREO / MONO
9	100531	EAR CUP, PRINTED AND DRILLED, MIC & NON MIC SIDE	25	100393	CLIP, ANTI-ROTATION, YOKE, PLASTIC	41	100508	WASHER
10	100362	CLIP, CROSS-OVER, WIRE, PLASTIC	26	100514	HEADBAND, METAL, STANDARD	42	100135	WASHER
11	100522	SCREW, 8-32 X 1/2, PHILLIPS HEAD	27	100516	BRACKET, YOKE SUPPORT WITH TANG	43	100130	TERMINAL, SOLDER
12	100521	SCREW, 8-32 X 3/8, PHILLIPS HEAD	28	100385	WASHER, SPRING, BOOM ADAPTER	44	100221	WIRE, JUMPER, #22, 4 INCHES
13	100523	SCREW, 8-32 X 5/8, PHILLIPS HEAD	29	100408	WASHER, GROOVED BOOM	45	900123	EAR SEAL, FOAM FILLED, SET OF TWO
14	100515	YOKE, EAR CUP MOUNT, METAL	30	800012	CABLE, HEADSET, STEREO	46	100674	OPTIONAL - HEADBAND, METAL, LARGE
15	100368	KNOB, MICROPHONE BOOM ADAPTER, PLASTIC	31	800039	CABLE, MICROPHONE BOOM, 12 INCH	47	100673	OPTIONAL - HEADBAND, METAL, YOUTH
16	900124	EAR SEAL, GEL FILLED, SET OF TWO	32	100752	HEADBAND EXTRUSION, 6.25 IN., BLANK			